

CLASSIC

Disassembly and repair instructions

Locker



Removal/replacement

Spare parts
Door removal / replacement
Hook removal / replacement

Page 2
Page 3-8
Page 9

Disassembly & Recycling

Recycling

Page 10


Save this document for future use.
This document provides information that may be subject to change without prior notice.

CLASSIC

Available spare parts

Locker

Available spare parts




No.	AJ article	Description	Benämning
1	60526	Hook	Krok
2	60675	Rivet	Popnit
3	60673	Left door stopper	Vänster dörrstopp
3	60672	Right door stopper	Höger dörrstopp
4	60671	Left riveting plate	Vänster nitbeslag
3	60670	Right riveting plate	Höger nitbeslag
5	60676	Plastic grommet	Genomföring
6	60682	Left hinge plate	Vänster gångjärnsbeslag
6	60679	Right hinge plate	Höger gångjärnsbeslag
7	60674	Hinge	Gångjärn

CLASSIC

Locker

Door removal/replacement

1




CLASSIC

Locker

Door removal/replacement

2




CLASSIC

Locker

Door removal/replacement

3




CLASSIC

Door reinstall

Locker

1







CLASSIC

Door reinstall

Locker

2




CLASSIC

Door reinstall

Locker

3






CLASSIC

Locker

Hook removal / reinstall


1



CLASSIC

Recycling

Locker



PARTS DIAGRAM AND MATERIALS MATERIALSPECIFIKATION

Part no.	Description / Beskrivning	Material
1	Locker / Skåp	Metal / Metall
2	Plastic grommet / Genomföring	Plastic / Plast



RECYCLING

To disassemble the furniture for proper recycling, start by removing all screws and fasteners, then separate materials like plastic, metal, and fabric before taking them to the respective recycling facilities.



ÅTERVINNING

För att demontera möbelen för återvinning, börja med att ta bort alla skruvar och fästordningar, sedan separera material som plast, metall och tyg innan du tar dem till respektive återvinningsanläggningar.