

QBUS

Disassembly and repair instructions

Side cabinet



Removal/replacement

Spare parts

Lock

Undermount drawer slides

Page 2

Page 3

Page 4

Disassembly & Recycling

Frame

Recycling


Page 6

Page 10

Save this document for future use.




This document provides information that may be subject to change without prior notice.

Available spare parts




No.	Reference ID	AJ article	Description	Benämning
1		60332	Complete lock with screws and fittings	Komplett lås med skruv och beslag
2		62832	Lock	Lås
3	A61090	61090	Metal cover ring	Metallring
4	SK3015	62090	Screw 3x20 mm	Skruv 3x20mm
5	BE0011	61705	Metal hitch for lock	Låsvinkel
6	SK3029	61706	Screw 3,5x13 mm	Skruv 3,5x13 mm


Lock removal/replacement



Undermount drawer slide removal/replacement









1




Undermount drawer slide removal/replacement

2









1




2




Frame disassembly

3





4



Frame disassembly

5





RECYCLING

To disassemble the furniture for proper recycling, start by removing all screws and fasteners, then separate materials like plastic, metal, and fabric before taking them to the respective recycling facilities.



ÅTERVINNING

För att demontera möbelen för återvinning, börja med att ta bort alla skruvar och fästordningar, sedan separera material som plast, metall och tyg innan du tar dem till respektive återvinningsanläggningar.

PARTS DIAGRAM AND MATERIALS

Part no.	Description	Material
1	Cabinet	Melamine faced chipboard (Wood)
2	Drawer guide	Plastic
3	Metal hitch for lock	Metal
4	Drawer guide	Plastic
5	Feet	Plastic
6	Drawer slides	Metal
7	Wheel	Metal
8	Screw	Metal
9	Lock	Metal